

Grill MAX

RECOMMENDATIONS FOR CARE AND SAFETY.

- 1 - Assemble it only on flat and safe surfaces.
- 2 - Be careful when touching grill borders - they can cut.
- 3 - Make sure legs are firm on the ground.
- 4 - Do not use inflammable liquid to light fire.
- 5 - We advise to burn charcoal for 15 to 30 mins. before starting food preparation.
- 6 - Do not carry grill when lit.
- 7 - Keep children and animals at a certain distance from grill for safety reasons.
- 8 - Do not use grill in closed environments or without adequate ventilation.
- 9 - Remember products like grills retain heat even when seemingly cool.
- 10 - When cleaning, carefully remove ashes and residues (charcoal, salt, others).
- 11 - Avoid using water to quench fire and clean grill.
- 12 - For better upkeeping of grill after cleaning spread mineral oil to protect product against rust.
- 13 - Remember that fire and salt are highly corrosive products.
- 14 - The paint used has a water-based solvent which is not aggressive to the environment and has a merely decorative function, protecting the product the first time it is used.